


Operating Manual

PM-9208 *Multi-Channel Monitor Panel*



©Copyright 2004 Inter-M Corporation

interM

Contents

| | |
|----------------------------------|-----------|
| Welcome | 3 |
| Unpacking | 3 |
| Warnings | 3 |
| Operation..... | 5 |
| Features | 6 |
| Front Panel Controls..... | 7 |
| Rear Panel Controls | 8 |
| Connection Diagram..... | 9 |
| Schematic Diagram | 10 |
| Specifications..... | 11 |

Welcome

A personal welcome to you from the management and employees of Inter-M

Thank you for purchasing this fine Inter-M product. All of us here at Inter-M are dedicated to providing you with the highest quality products and the best value.

We sincerely trust this product will provide you with years of satisfactory service, but if anything is not to your complete satisfaction, we will endeavor to make things right.

Welcome to Inter-M, and thank you for becoming a part of our worldwide extended family!

Unpacking

Please take a few minutes to read this brief manual and familiarize yourself with the important information regarding product features, setup and operation.

As with most electronic devices, we strongly recommend you retain the original packaging. In the unlikely event the product must be returned for servicing, the original packaging (or reasonable equivalent) is required.

Warnings




Environment

Never place this product in an environment that could alter its performance or reduce its service life. Such environments are usually characterized by high levels of heat, dust, moisture, or vibration.

Safety

1. Read these instructions carefully.
2. Follow all instructions.
3. Keep all warnings.
4. Do not operate this apparatus near water.
5. Clean only with a damp cloth.
6. Do not block any of the ventilation openings.
7. Install in accordance with the instructions in this manual.

8. Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades, with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where it is attached to the apparatus.
11. Use only the attachments/accessories specified.
12. Use only with a cart, stand, tripod, bracket, or table specified, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid overturning.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

| | |
|--|---|
|  <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p> |  <p>This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.</p> |
| <p>WARNING</p> <p>To prevent fire or shock hazard, do not expose the unit to rain or moisture.</p> |  <p>This symbol is intended to alert the user to the presence of important operation and maintenance (servicing) instructions in the literature accompanying the appliance.</p> |
| <p>Caution: To prevent electric shock do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.</p> | |
| <p>Attention: Pour prévenir les chocs électriques ne pas utiliser cette fiche polarisée avec un prolongateur, une prise de courant ou une autre sortie de courant, sauf si les lames peuvent être insérées à fond sans en laisser aucune partie à découvert.</p> | |
| <p>*Do not install this equipment in a confined space such as a book case or similar unit. *The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus. *Worded: "WARNING FOR YOUR PROTECTION PLEASE READ THE FOLLOWING-WATER AND MOISTURE: Unit should not be used near water(e.g. near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc). Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings."</p> | |

Operation

Make certain that speakers and input sources are properly connected before switching on.

Keep volume levels at minimum gain and equalization set to 0dB position before switching on.

When the AC Mains power switch is pressed, this unit starts operation with tuner display. NOTE: The system's operation is delayed by approximately three seconds after pressing the AC Mains power switch. This is due to the built-in protection circuitry, designed to protect the speakers and other system components.

PM-9208 Multi-Channel Monitor Panel

Features

Output Power Monitoring

- Eight-segment, three-color LED meters for easy monitoring of up to eight channels.


Selective Monitoring Function

- Eight channel selector switches allow you to easily monitor output of up to eight amplifiers.

Built-In Monitor Speaker

- Front-panel monitor speaker for quick audio access to selected channels.

Front Panel Controls



1. Level Meter

Eight-segment LED meters indicate the output level of each channel.

2. Monitor Level Select

Six radio-style switches select the function and level of the front-panel monitor speaker. Switches select between OFF, -24dB, -18dB, -12dB, -6dB and 0dB.

3. Status Indicator LEDs

LEDs in selected switches light to indicate status.


4. Monitor Speaker

High-powered, full-fidelity speaker for convenient monitoring of selected amplifier channel.

5. Channel Selector Switches 1-8

Eight radio-style switches select any channel's output to be monitored by the front panel speaker (4).

Rear Panel Controls



1. DC Input Terminals

Connect a 24VDC battery source to these terminals. Make certain the red terminal is connected to the battery's positive (+) side, and the black terminal to the battery's negative (-) side.


2. Audio Input Terminals (Hot)

Connect the positive (+) output terminals of power amplifiers to these inputs for monitoring.


3. Audio Input Terminals (COM)

Connect the negative (-) output terminals of power amplifiers to these inputs for monitoring.

Connection Diagram



Schematic Diagram



Specifications

| | |
|-------------------------------------|------------------------|
| Outside Inputs | 8-100V or 70V inputs |
| LED Monitor Outputs | 8 simultaneous outputs |
| Monitor Speaker Output Power | 1.5W maximum |

GENERAL

| | |
|---------------------|---|
| Power Source | 24VDC |
| Weight | 3.8kg (8.6 lbs) |
| Dimensions | 482 mm(W) 88 mm(H) 280 mm (D) 19 in (W) 3.5 in (H) 11 in (D) |

Specifications and design subject to change without notice for product improvements.



Inter-M, Ltd. (Korea) began operations in 1983.

Since then, Inter-M has grown to become one of the largest manufacturers of professional audio and commercial sound electronics equipment in the world.

Inter-M has gained worldwide recognition for its own branded products, as well as private label manufacturing of electronics sold under other names (OEM).

The company is no longer just a Korean company, but rather a global company that is truly international in scope, with factories and offices in Korea and China, and sales and marketing operations located in Japan, Europe, and the U.S.A.

With more than 850 employees around the globe, Inter-M is well-poised for further growth and expansion.

INTER-M AMERICAS, INC.

1 EAST BEACON LIGHT LANE, CHESTER, PA, USA 19013-4409

TEL: (610) 874-8870, FAX: (610) 874-8890

Home Page:<http://www.inter-m.net>, E-mail: service@inter-m.net

INTER-M Corporation

SEOUL OFFICE: 653-5 BANGHAK-DONG, DOBONG-KU, SEOUL, KOREA

TEL: 82-2-2289-8140~8, FAX: 82-2-2289-8149

Home Page:<http://www.inter-m.com>, E-mail: export@inter-m.com